THE MUNICIPALITY OF LAMBTON SHORES

Waterline Installation Process

Step 1



Home Owner Takes Out Plumbing Permit and pays for new meter assembly, water connection fee and capital cost fee (if applicable)

Step 2

Home Owner calls in locate request 1-800-400-2255 or www.ontarioonecall.ca

Step 3

Home owner calls Lambton Shores 519-243-1400 to request inspection date/time

(48 hrs notice required)

Step 4

Home owner installs waterline (complete with Backflow Preventer)

Step 5

Waterline is inspected by County and Lambton Shores

Notes:

- **Wherever possible we will complete Steps 5 & 8 at the same time. When you call in Step 3 please indicate if this is possible.**
- **It is an offense under Bylaw 74-2007 for anyone other than Lambton Shores to operate the curbstop valve.**

Step 6

Home Owner backfills (buries) waterline

Step 7

Home Owner calls Lambton Shores 519-243-1400 for water meter installation

(5 days notice required)

Step 8

Lambton Shores installs water meter assembly

October 3, 2025